




ETS-EVO²

Time and Frequency Reference

Rev 1.0

Dichiarazione di conformità Declaration of conformity	
La Ditta <i>The Company</i>	DIGITAL INSTRUMENTS S.r.l. Via Parco degli Scout, 13 20091 BRESSO (MI) ITALY
Dichiara con la presente che il Prodotto <i>Herewith declares that the Product</i>	
Tipo / <i>Type</i>	Time and Frequency Reference
Modello / <i>Model</i>	ETS-EVO²
Serial Number	0250 /
Oggetto di questa dichiarazione è conforme ai seguenti standard o norme della Comunità Europea <i>Referred to by this declaration is in conformity with the following standards or normative documents of EC</i>	
Norme Europee Armonizzate <i>European Armonized Standards</i>	
CEI EN 61000-6-4:2007	Electromagnetic compatibility (EMC) - Part 6-4: Generic standards - Emission standard for industrial environments
CEI EN 61000-6-2:2006	Electromagnetic compatibility (EMC) - Part 6-2: Generic standards - Immunity for industrial environments
CEI EN 55011:2011	Limits and methods of measurement of radio disturbance characteristics of industrial, scientific and medical (ISM) radio-frequency equipment
CEI EN 61000-4-2:2011	Electromagnetic compatibility (EMC) - Part 4-2: Testing and measurement techniques - Electrostatic discharge immunity test
CEI EN 61000-4-3:2007+A1:2009+A2:2011	Electromagnetic compatibility (EMC) - Part 4-3: Testing and measurement techniques - Radiated, radio-frequency, electromagnetic field immunity test
CEI EN 61000-4-4:2006+A1:2010	Electromagnetic compatibility (EMC) - Part 4-4: Testing and measurement techniques - Electrical fast transient/burst immunity test
CEI EN 61000-4-5:2007	Electromagnetic compatibility (EMC) - Part 4-5: Testing and measurement techniques - Surge immunity test
CEI EN 61000-4-6:2011	Electromagnetic compatibility (EMC) - Part 4-6: Testing and measurement techniques - Immunity to conducted disturbances, induced by radio-frequency fields
CEI EN 61000-4-8:1997+A1:2001	Electromagnetic compatibility (EMC) - Part 4-8: Testing and measurement techniques - Power frequency magnetic field immunity test
CEI EN 61000-4-11:2010	Electromagnetic compatibility (EMC) - Part 4-11: Testing and measurement techniques - Voltage dips, short interruptions and voltage variations immunity tests
CEI EN 60204-1:2006+A1:2010	Safety of machinery - Electrical equipment of machines - Part 1: General requirements
Bresso, September 2014	DIGITAL INSTRUMENTS S.r.l. Via Parco degli Scout, 13 20091 BRESSO (MI) ITALY <i>Marco Genova</i> <i>Quality Assurance Manager</i>

Istruzioni di sicurezza Safety Instructions

Il dispositivo è stato progettato, costruito e collaudato in conformità alle normative richiamate nel Certificato di Conformità ed è stato rilasciato dal costruttore completamente testato secondo gli standard di sicurezza. Per mantenere questa condizione e assicurare la sicurezza d'uso, l'utente deve osservare tutte le istruzioni e segnalazioni di pericolo descritte in questo manuale.

This unit has been designed and tested in accordance with the EC Certificate of Conformity and has left the manufacturer's plant in a condition fully complying with safety standard. To maintain this condition and to ensure safe operation, the user must observe all the instructions and warnings given in this operating manual.

- **Prima di mettere in servizio il dispositivo, leggere attentamente ed integralmente le istruzioni per l'uso. Osservarle e seguirle in tutti i punti. Provvedere in modo che le istruzioni per l'uso siano sempre accessibili a tutti gli addetti.**

Prior to switching on the unit, please read carefully the instructions on the manual. Keep this manual available for all every user of this equipment.

- **Il terminale PE sul dispositivo deve essere connesso al conduttore PE prima di eseguire qualsiasi altra connessione. L'installazione ed il cablaggio devono essere eseguiti da personale tecnico qualificato.**

The PE terminal of the unit must first be connected to the PE conductor on site before any other connections are made. Installation and cabling of the unit to be performed only by qualified technical personnel.

- **Lo strumento supporta alimentazione AC wide range da 95 Vac a 240 Vac e deve essere connesso tramite protezione con corrente nominale massima pari a 16A.**

This unit may be operate from wide range AC supply networks from 95 Vac to 240 Vac fused with max. 16A.

- **Lo strumento supporta alimentazione DC wide range da 20 Vdc a 50 Vdc e deve essere connesso tramite protezione con corrente nominale massima pari a 5A. Il circuito di protezione contro l'inversione di polarità è implementato a bordo.**

This unit may be operate from wide range DC supply networks from 20 Vdc to 50Vdc fused with max. 5A. Circuit against polarity inversion is also implemented.

Le condizioni di sicurezza vanno testate ad ogni sostituzione. Ispezione visiva dei cavi, stato dell'isolamento, corrente di dispersione, stato del connettore PE e test funzionale.

A safety test must be performed after each replacement of part. Visual inspections, PE conductor test, insulation resistance, leakage-current measurement, functional test.

- **Non interrompere il conduttore PE in nessun caso. Un'interruzione del cavo PE rende l'apparato elettricamente pericoloso.**

It is not permissible to interrupt PE conductor intentionally, neither in the incoming cable nor on the unit itself as this may cause the unit become electrically hazardous.

- **Ogni riparazione, manutenzione e sostituzione del dispositivo deve essere eseguita unicamente da personale autorizzato dalla Digital Instruments.**

Any adjustments, replacements of parts, maintenance or repair may be carried out only by authorized Digital Instruments technical personnel.





- **Assicurarsi che ogni collegamento con dispositivi informatici sia eseguito secondo IEC950/EN60950**

Ensure that the connections with information technology equipment comply with IEC950/EN60950

Simboli di sicurezza Safety Symbols

Sono presenti sul dispositivo e nella documentazione simboli utilizzati per la segnalazione di segnalazione conformi alle specifiche IEC61010-1 II.

Safety-related symbols used on equipment and documentation comply with IEC 61010-1 II.

	<ul style="list-style-type: none"> • SIMBOLO DIRECT CURRENT IEC 417, N°5031 Vdc may be used on rating labels
	<ul style="list-style-type: none"> • SIMBOLO ALTERNATING CURRENT IEC 417, N°5032 For rating labels, the symbol is typically replaced by V and Hz as in 230V, 50Hz.
	<ul style="list-style-type: none"> • SIMBOLO PROTECTIVE CONDUCTOR TERMINAL IEC 417, N°5019 This symbol is specifically reserved for the PROTECTIVE CONDUCTOR TERMINAL and no other. It is placed at the equipment earthing point and is mandatory for all grounded equipment
	<ul style="list-style-type: none"> • SIMBOLO CAUTION ISO 3864, N°B.3.1 used to direct the user to the instruction manual where it is necessary to follow certain specified instructions where safety is involved.

Changelog

Rev.	Note	Data
1.0	First review	22/09/2014

ETS-EVO²

Time and Frequency Reference

Table of Contents

Summary	6
Front View	7
Rear View	7
Connectors details	8
Main Operation	9
GPS	9
NTP	9
PTP (IEEE 1588)	10
IRIG-B	11
Date and time	12
Switchover Function	13
Switchover threshold	13
WEB interface	18
Serial Protocols	23
Event Log	25
SNMP Trap Management	26
User Account	26
Custom Settings	27
Board Bring-Up	28
Appendix A: Quality Factor	29
General Review	29
GPS antenna positioning	29
Quality Factor	30
Statistics	31
Automatic Site Survey	31
Appendix B: FAQ	32
Appendix C: Changelog	33
Software Versions	33
Hardware Versions	33
Assistance	34
Technical Data	35

Summary

This manual provides to the user of the apparatus *ETS-EVO²* all the information necessary for proper operation. The informations include the normal installation procedures and any data on the maintenance and programming in order to facilitate interventions in the field.



ETS-EVO² represents an upgrade of a previous model called ETS-EVO (that has been discontinued). Please keep in mind that the two versions use different and incompatible software versions. Furthermore ETS-EVO² features a much more powerful ARM based dual core CPU that outperforms the older model.

ETS-EVO² is a very flexible solution to generate high-stability Time (PPS, IRIG code, NTP/PTP) and Frequency (10 MHz) reference signals.

ETS-EVO² accepts inputs from a GPS radio, via an external input or via the NTP/PTP protocol.

ETS-EVO² is able to generate programmable pulses and has event time function through dry contact.

ETS-EVO² also features an integrated full-featured PTP and NTP server to provide date and time synchronization to PCs over network.

ETS-EVO² is provided with a double RJ-45 10/100/1000 Gigabit Ethernet port.

ETS-EVO² can be configured as PTPv2 Grandmaster clock, PTPv2 Slave, NTP Stratum 1 server or relay.

ETS-EVO² can be managed locally from the LCD panel and remotely via web through a very intuitive interface or via the well-known SNMP protocol.

Multiple sources can be used as backup to provide a redundant mean of synchronization. Automatic switchover based on customizable priorities is implemented, without any noticeable interruption in the outputted time-frequency signals.

ETS-EVO² has double Power Supply Unit, to ensure best safety and uninterrupted work.

ETS-EVO² is in metallic box of sizes 1U 19'' for rack installation.

Note

This document may contain confidential and or reserved material of property of Digital Instruments S.r.l. It cannot be reproduced, used or shown to third parties for any other scope than the intended one.




WARNING: Before inserting the power supply please carefully read all instructions for proper installation.


Front View

The front panel appears as in the following figure.

On the left side there is a row of status LEDs, whilst on the right can be found an alphanumeric 20x4 display and a keyboard.




The LCD display is used to navigate through the various menus in order to manage the device.



By pushing the right keyboard button it's possible to enter the main menu of the **EVO-EVO²**.

Rear View


The figure below shows the back of the **ETS-EVO²** with the positions of the connectors and their electrical wiring.



ETS-EVO² does not provide any supply switch.

Connectors details


TLS connector (Remote signals)



The 8 poles TLS connector provides the following information on the various pins (from left to right):

- PIN 1: Common contact
- PIN 2: Closed contact → Right power supply provided
- PIN 3: Closed contact → Left power supply provided
- PIN 4: Closed contact → GPS reference present and valid
- PIN 5: Closed contact → PTP reference present and valid
- PIN 6: Closed contact → IRIG-B reference present and valid
- PIN 7: Closed contact → NTP protocol working
- PIN 8: Closed contact → Synchronization completed

TLC connector (Remote controls)



The 8 poles TLC connector provides the following commands on the various pins (from left to right):

- PIN 1-2: Powered contact → Manual switch
- PIN 3-4: Powered contact → Automatic switch
- PIN 5-6: Powered contact → Switch over next reference
- PIN 7-8: Powered contact → Switch over previous reference

Main Operation

The main purpose of the *ETS-EVO*² is to provide stable output signals of Time (PPS, IRIG code, NTP/PTP) and Frequency (10 MHz), and to enable the synchronization of the network.

This is allowed by the application of algorithms, tuning an high-stability internal oscillator.

Peculiarities of the *ETS-EVO*² is the possibility to accept input from four different sources:

1. GPS
2. NTP
3. PTP (IEEE 1588)
4. IRIG-B

In this manner it is possible to switch from one source to another, if a fault occurs.

The strong difference between the various sources is a major strength as it makes the same apparatus both very flexible to suit the needs of the customer and very strong in order to better cope with possible failures of a type of source (for example, the loss of accuracy of the GPS signal).

Even in case of a switch, references of Time / Frequency provided are kept stables.


GPS

The apparatus is internally equipped with a GPS receiver especially suitable for use as a time reference. The GPS receiver is able to reproduce the local PPS signal relative to UTC second with a precision of typically ± 100 ns. With this feature is possible to regulate the internal oscillator apparatus for producing a high-stability output signal of 10 MHz and PPS.

NTP

The NTP (Network Time Protocol) is a well-established standard for synchronization of PCs and other devices on the Internet or an Intranet network.

The accuracy of the order of tens of milliseconds, can be considered adequate for most situations. Its flexibility and strength, thanks to the many servers widely available, making it a very smart choice for time synchronization.




PTP (IEEE 1588)

The *ETS-EVO²* supports the IEEE 1588-2008 (version 2), also known as *Precision Time Protocol*, both as master and slave. When connected to an appropriate device compatible to the IEEE 1588 standard is able to synchronize the slave apparatus with a precision well below the micro-second.


Note that using network switches non-compliant with IEEE 1588, variable delays in the order of some tens of microseconds are introduced (as noted in the official website of the Protocol <http://ieee1588.nist.gov/switch.htm>).

The IEEE 1588 bases its operation on the calculation of the transit time of PTP packets from the master to the slave (and slave to master).

These latencies are calculated using a simple exchange of messages between master and slave that are associated with timestamps managed at the hardware level.



Once reconstructed the one-way-delay it is possible to use it to correct the clock of the slave and lock it to the master. Below is shown the pattern of the loop relative to the clock tuning based on PTP.



IRIG-B

The device can accept in input and provide in output (on BNC and optical connectors) an IRIG-B stream of type 006, compliant with following code:

Bit position	Information transmitted
0	Position identifier P_R (seconds' boundary marker)
1–4	Units of seconds
6–8	Tens of seconds
9	Position identifier P_1
10–13	Units of minutes
15–17	Tens of minutes
19	Position identifier P_2
20–23	Units of hours
25–26	Tens of hours
29	Position identifier P_3
30–33	Units of days
35–38	Tens of days
39	Position identifier P_4
40–41	Hundreds of days
49	Position identifier P_5
50–53	Units of year or control function bits
55–58	Tens of year or control function bits
59	Position identifier P_6
60–68	Control function bits
69	Position identifier P_7
70–78	Control function bits
79	Position identifier P_8
80–88	Nine lowest significant bits of time of day in straight binary seconds (bit 80 $\rightarrow 2^0$... bit 88 $\rightarrow 2^8$)
89	Position Identifier P_9
90–97	Eight most significant bits of time of day in straight binary seconds (bit 90 $\rightarrow 2^9$... bit 97 $\rightarrow 2^{16}$)
99	Position identifier P_0
Note: Bits not listed are index markers, and are sent as binary zeroes.	

It was also implemented part of the standard 1344-1995. The offset compared to the UTC time can be set using the Timezone of the apparatus. Changes of DST or leap second are not currently notified (always returned as 0).

IRIG-B Pos ID	CTRLB IT#	Designation	Explanation
P50	1	Year, BCD 1	Last 2 digits of year in BCD
P51	2	Year, BCD 2	IBID
P52	3	Year, BCD 4	IBID
P53	4	Year, BCD 8	IBID
P54	5	Not used	Unassigned
P55	6	Year, BCD 10	Last 2 digits of year in BCD
P56	7	Year, BCD 20	IBID
P57	8	Year, BCD 40	IBID
P58	9	Year, BCD 80	IBID
P59	-	P6	Position identifier # 6
P 60	10	Leap second pending (LSP)	Becomes 1 up to 59 s BEFORE leap second insert
P 61	11	Leap second (LS)	0 = Add leap second, 1 = Delete leap second
P62	12	Daylight saving pending (DSP)	Becomes 1 up to 59 s BEFORE DST change
P63	13	Daylight savings time (DST)	Becomes 1 during DST
P 64	14	Time offset sign	Time offset sign – 0=+, 1=-
P65	15	Time offset-binary 1	Offset from coded IRIG-B time to UTC time IRIG coded time plus time offset (including sign) equals UTC time at all times (offset will change during daylight savings)
P 66	16	Time offset-binary 2	
P 67	17	Time offset-binary 4	
P68	18	Time offset-binary 8	
P 69	-	P7	Position identifier # 7
P70	19	Time offset-0.5 hour	0 = none, 1 = additional 0.5 h time offset
P71	20	Time quality	4 b code representing approx. clock time error 0000 = clock locked, maximum accuracy 1111 = clock failed, data unreliable.
P72	21	Time quality	
P73	22	Time quality	
P74	23	Time quality	
P75	24	PARITY	Parity on all preceding data bits
P76	25	Not used	Unassigned
P77	26	Not used	Unassigned
P78	27	Not used	Unassigned
P79	-	P8	Position identifier # 8

Date and time

The device disciplines its internal clock from the selected reference (GPS, PTP, IRIG-B, NTP) and distributes it with the following rules:

- NTP (UTC time as per standard)
- PTP (UTC time)
- IRIG-B (localtime configured by user with the Timezone setting)

Switchover Function

ETS-EVO² allows the possibility to switch the disciplining of its internal timebase selecting one of many sources. This exchange can be configured to run automatically upon occurrence of an alarm condition, such as:

- PPS signal absence
- disconnection of the antenna
- error in the external source
- error in the PTP protocol

In the log are reported the reason of the switch:

Mweb	→ user defined switch from web
Msnmp	→ user defined switch from SNMP
Aser	→ automatic switch due to serial connection lack of GPS
Aant	→ automatic switch due to connection lack of GPS antenna
Apref	→ automatic switch to the higher priority source
Aptp	→ automatic switch caused by errors in the PTP protocol


Switchover threshold

This variable allows to define a time interval (in seconds) that must elapse between the time when an error has been identified and when it will be exchanged effectively. If during this time the error will disappear, the exchange will be deleted.

Characterization of Sources

TES-B01 was also designed to compare the quality of the different sources provided in input, analyzing the ratio $\Delta f / f$ (variation of the frequency value on the nominal frequency) of each source. This analysis is supported by a graph (that can be generated by the *Stability Chart* button in the *Main Panel*) which shows the trend of these ratios over time.

The step used is 5 minutes, while the values are expressed in nanoseconds.



Moreover, is also possible to display both on web interface (the *View* section of *Main Panel*), and on the LCD screen (below the status of each source), the delay, expressed in nanoseconds, between the PPS generated from the apparatus output and the three different tuning sources.

To correctly perform the characterization of various sources it's good configure the equipment with the following settings:


- Manual mode exchange
- GPS Source selected

It is good practice to check that the PPS generated by the GPS radio is valid and its delay is less than 100 ns (also visible from GPS → status).

It is also possible to display the progress of these distances over time (using the button *Distance Chart* in the *Main Panel*).

Graph Menu

The graph menu can be navigated by pressing the four directions provided by the keyboard.



To enter the first level from level zero (**ROOT**) is enough to press the **RIGHT** key, that works as **Enter** key. At this point all the first level menus are visible in a cyclic loop with the pressing of the **UP** and **DOWN** keys. The currently selected menu is recognized by an arrow placed on its left side. It is possible to enter it by pressing the **RIGHT** key.

```
Setup
→ Mode Menu
Network
Settings
```

By entering a menu is possible to view all of its associated submenus by pressing the **UP** and **DOWN** keys. The **RIGHT** key permits, once again, to enter the selected submenu in the view mode. By pressing **RIGHT** again is possible to modify the value of the parameter (an arrow indicates the modify mode). **RIGHT (Enter)** confirms the choice, whilst **LEFT (Escape)** discards it.

```
Mode Menu
Local/Remote
→ Local
```

The changing of parameters from front panel is only supported in local mode.

From the level 0 (**ROOT**) it is possible to change the contrast of the LCD screen by pushing the **UP** and **DOWN** keys.

In the following table the whole graph is shown, with the associated permitted values for each parameter.

Front Panel Menu		Values
Mode Menu	Local/Remote	Local / Remote
	Autoremove	ON / OFF
Network	IP Address	0.0.0.0 ÷ 255.255.255.255
	Gateway	0.0.0.0 ÷ 255.255.255.255
	Netmask	0.0.0.0 ÷ 255.255.255.255
	MAC Address	00:00:00:00:00:00 ÷ ff:ff:ff:ff:ff:ff
	DHCP	ON / OFF
	Trap Dest	0.0.0.0 ÷ 255.255.255.255
	Trap Port	0 ÷ 65535
Board Settings	Source	GPS / PTP1 / PTP2 / IRIG-B (only possible in manual switch)
	Manual/Auto	Manual / Auto
	Switchover	0 ÷ 36000s (10 hours)
	Priority	GPS: 0 ÷ 4 PTP1: 0 ÷ 4 PTP2: 0 ÷ 4 IRIG-B: 0 ÷ 4 0 = [], 1 =[#], 2=[##], 3=[###], 4=[####]
	PPS Mux Out	PPS, IRIG-B, PULSE #1, PULSE #2
	IRIG-B Mux Out	PPS, IRIG-B, PULSE #1, PULSE #2
Board Status	Info	SW/HW version
	Disciplining	Vtune value: 0 ÷ 65536 PPS Sync: ON / OFF
	TLC	4 values → 0, 1
	TLS	7 values → 0, 1
	Supply	AC L: ON / OFF AC R: ON / OFF
GPS	Status	Radio: OK / Unplugged TD: <value> [ns]
	Positioning Mode	Normal Position, Position Hold, Altitude Hold, Autosite Survey
	Latitude	-89° 59' 59'' ÷ 89° 59' 59''
	Longitude	-179° 59' 59'' ÷ 179° 59' 59''
	Height	0 ÷ 18000 mt
	Cable Delay	0 ÷ 10000 ns
	Show Ch Status	Ch, S/N, Elevation, Azimuth
	Show Global Info	Tracked Sats, Visible Sats, PPS Signal, Antenna
PTP #1	Status	Status: UNKNOWN / SLAVE / MASTER / ... TD: <value> [ns]
	Enabled	ON / OFF
	Board Type	Slave / Master
	Jitter	1 ÷ 255
	Unicast	ON / OFF
	Dest	0.0.0.0 ÷ 255.255.255.255
	Priority	0 ÷ 255
	Profile	DEFAULT, TELECOM, POWER, CUSTOM
PTP #2	Status	Status: UNKNOWN / SLAVE / MASTER / ... TD: <value> [ns]
	Enabled	ON / OFF
	Board Type	Slave / Master
	Jitter	1 ÷ 255
	Unicast	ON / OFF

	Dest	0.0.0.0 ÷ 255.255.255.255
	Priority	0 ÷ 255
	Profile	DEFAULT, TELECOM, POWER, CUSTOM
IRIG-B	Status	Present YES / NO Date Date and Time TD: <value> [ns]
	IRIG-B Mux In	Optical / Electrical
Setup	Date & Time	00:00:00 01/01/01 ÷ 23:59:59 31/12/99
	Timezone	-12 ÷ 12
	Clear Log	Clear
	Restore Defaults	Restore
	Reboot	Reboot


WEB interface

The *ETS-EVO²* is managed by the network using a common browser by simply connecting to the IP address associated with it.

Main panel

From the main panel, the user can view the status of the source, indicating the distance (time delay) of the Time signal from Time signal reconstructed by the specific source.

Clicking on the source, the user can select it to the internal oscillator tuning, if the exchange is set on *Manual*.



From the tabs on the left side it's possible to retrieve the status of each source.



The position of the satellites can be seen by clicking on Polar view.



Network Configuration Panel

Board ID

Allows to define a name to the apparatus, useful for identifying it on the network

Trap Dest

Allows to configure the destination server of the traps related to the events.

IP

Allows to set up the IP address associated to the the specific network interface. To activate the changes, system needs to restart.

Netmask

Allows to set the netmask associated to specific network interface. To activate the changes, system needs to restart.

Gateway

Allows to set the gateway associated with specific network interface. To activate the changes, system needs to restart.

Reset to default

Restores the original configuration

Reboot the board

Restarts the device

Date & Time

Allows to view/set the date and time of the apparatus. Note that this will still be automatically updated to that received by satellite.

Timezone

Allows to set the UTC offset for proper time visualization.


Guest Account Settings

Allows to change the credentials of the user account (see below for more details)

Admin Account Settings

Allows to change the credentials for the administrator account (see below for more details)

Sources Config Panel



GPS

Cable Delay

Allows the setting of the length of the cable that separates the GPS antenna from the apparatus, so as to compensate the signal propagation delays.

Positioning Mode

Allows to set the calculating mode of the geographic coordinates done by GPS receiver. If derived from information provided by satellites or maintain the one set by the user. The mode "Altitude Hold" may not be available on all versions of the GPS radio.

PTP

Enable

Allows to switch on or off the PTP.

Type

Allows to choose to configure the device as a Grandmaster or a Slave.

Profile


Allows to choose to choose between some predefined profiles for common configurations.

Poll

Specify the interval between broadcast packets

SNMP*Configuration*

Allows to change the configuration of the SNMP server (please refer to the SNMPd² syntax)

Board Config Panel


The screenshot shows the Board Config Panel with the following settings:

- Switch Mode:** manual
- Switchover:** 30 sec
- PPS Mux:** Output 1: PPS, Output 2: PPS
- IRIG-B Mux:** Input: AUTO, Output: IRIG-B
- Frequency Lock:** Rubidium
- SyncESSM:** PRC
- Priority:** GPS: 5, PTP #1: 4, PTP #2: 3, IRIG-B: 2, E1: 5
- IRIG Output:** Type: IRIG-B
- Serial Protocol:** Value: SERIAL CONSOLE
- Firmware Update:** Includes an Upload button, a Browse... button, and a Download button for the available CONFIG file.

© 2014 Digital Instruments Srl. All rights reserved.

Switch Mode

Allows to set the type of switching (manual or automatic)

Switchover

Allows to modify the switch-over time

Frequency Lock

Allows to enable the Synchronous Ethernet mode (master or slave) or to synchronize to a Rubidium

SyncE SSM

When SyncE is enabled this is the SSM value that is sent in the ESMC messages

Priority

Set the priority of each source for the automatic switch (a higher value means a higher priority, 0 disables the source)

Serial Protocol

Allows to configure the behaviour of the serial port (for more details please refer to section *Serial Protocols*)

Firmware Update

Allows to load a file for an eventual firmware upgrade and to load/store the configuration in use

² <http://www.net-snmp.org/docs/man/snmpd.conf.html>

Serial Protocols

The ETS-EVO² has a serial RS-232 interface on the back that can be used as a serial console or configured to output a serial protocol.

The PC must be provided with a serial connector DB9M (9 pins).
The signals on each pin are shown in the following table:

Pin	Signal	I/O	Signal description
1	DCD	I	Data Carrier Detect (optional)
2	RxD	I	Received Data
3	TxD	O	Transmitted Data
4	DTR	O	Data Terminal Ready
5	GND	-	Signal Ground
6	DSR	I	Data Set Ready
7	RTS	O	Request to Send
8	CTS	I	Clear to Send
9	RI/+5...+15V	I/O	Ring Indicator (optional) or auxiliary supply voltage (optional)



A null-modem cable must be used, with the tx and rx lines switched (to let two DTE devices to talk). It may be that some USB→RS232 adapters would cause problems with the electrical criteria.

Serial Console

When configured as a serial console it is possible to login on the device with the serial configuration **115200/8-N-1** and typing **root** as login and **root** as password.

Uni Erlangen

The Uni Erlangen format consists of 66 ASCII characters formatted in the following way:

<STX>dd.mm.yy; w; hh:mm:ss; +uu:uu; uvxyzab; ll.lllln lll.lllle hhhh<ETX>

- <STX>** = start-of-text, ASCII code 0x02
- dd.mm.yy** = day of month, month, year of the century, separated by dots
- w** = day of week (1..7, Monday = 1)
- hh:mm:ss** = hour, minute, second, separated by colons
- +uu:uu** = offset to UTC in hours and minutes, preceded by + or -
- u** = '#' if time is not synchronized, else ''
- v** = '*' if position has not been verified, else ''
- x** = 'S' if daylight saving time is active, else ''
- y** = '!' during the hour preceding start or end of daylight saving time, else ''
- z** = 'A' during the hour preceding a leap second, else ''
- a** = 'R' alternate antenna (reminiscent of PZF5xx), usually '' for GPS receivers
- b** = 'L' during a leap second, i.e. if the seconds field is 60, else ''
- ll.lllln** = position latitude in degrees, 'n' can actually be 'N' or 'S', i.e. North or South
- lll.lllle** = position longitude in degrees, 'e' can actually be 'E' or 'W', i.e. East or West
- hhhh** = position altitude in meters, always followed by 'm'
- <ETX>** = end-of-text, ASCII code 0x03

The serial port must be configured for using the format **19200/8-E-1**.

ABB SPA Time String

The ABB SPA Date and time string format consists of 32 characters formatted in the following way:

>900WD:yy-mm-dd hh.mm;ss.sss:cc<CR>

yy-mm-dd = year of the century , month and day of month, separated by dashes
 hh.mm = hours and minutes, separated by colons
 ss.sss = seconds and milliseconds, separated by colons
 cc = checksum (EXCLUSIVE-OR of the previous characters)

The serial port must be configured for using the format **9600/7-E-1**.

NMEA Time Strings

The following NMEA strings are being outputted on the serial port:

ZDA - Date and Time

\$GPZDA, hhmmss.ss, dd, mm, yyyy, xx, yy*CC
 \$GPZDA, 201530.00, 04, 07, 2002, 00, 00*60

hhmmss = HrMinSec(UTC)
 dd,mm,yyy = Day,Month,Year
 xx = local zone hours -13..13
 yy = local zone minutes 0..59
 *CC = checksum

GGA - essential fix data which provide 3D location and accuracy data.

\$GPGGA, 123519, 4807.038, N, 01131.000, E, 1, 08, 0.9, 545.4, M, 46.9, M, , *47

GGA = Global Positioning System Fix Data
 123519 = Fix taken at 12:35:19 UTC
 4807.038,N = Latitude 48 deg 07.038' N
 01131.000,E = Longitude 11 deg 31.000' E
 1 = Fix quality:
 0 = invalid
 1 = GPS fix (SPS)
 2 = DGPS fix
 3 = PPS fix
 4 = Real Time Kinematic
 5 = Float RTK
 6 = estimated (dead reckoning) (2.3 feature)
 7 = Manual input mode
 8 = Simulation mode
 08 = Number of satellites being tracked
 0.9 = Horizontal dilution of position
 545.4,M = Altitude, Meters, above mean sea level
 46.9,M = Height of geoid (mean sea level) above WGS84 ellipsoid
 (empty field) = time in seconds since last DGPS update
 (empty field) = DGPS station ID number
 *47 = the checksum data, always begins with *

The serial port must be configured for using the format **9600/8-N-1**.

Event Log

On the WEB is available the apparatus log from *Event log* section.
50 entries are presented.

It is possible to delete the logs and save them in *csv*. format.

Id	Date	Time	Code	Description
1	09/12/09	10:41:59	003	PPS Al. 1
2	09/12/09	10:41:59	003	PPS Al. 2
3	09/12/09	10:41:59	003	PPS Al. 3
4	09/12/09	10:41:59	003	PPS Al. 4
5	09/12/09	10:41:59	003	PPS Al. 5
6	09/12/09	10:41:59	003	PPS Al. 6
7	09/12/09	10:50:51	011	PPS Syncr
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				

Events related to the board


Event Code 001	Power ON	→ Apparatus on
Event Code 002	Switch	→ Switching on GPS / EXT / E1 source
Event Code 003	PPS alarm	→ Alarm on PPS (1÷4)
Event Code 004	Clock alarm	→ Alarm on 10 MHz (1÷4) signal
Event Code 005	GPS Serial	→ Detection or loss of connectivity of the GPS radio
Event Code 006	Supply	→ Insertion or removal of a power supply (L, R)
Event Code 007	Switch Alarm	→ More than 3 exchanges in less than 5 minutes
Event Code 008	GPS PPS	→ Status change of PPS from satellite
Event Code 009	GPS Antenna	→ GPS antenna connection or disconnection
Event Code 010	Bad Vtune	→ Vtune incorrect value
Event Code 011	PPS Syncr	→ Synchronization completed
Event Code 018	PTP PPS	→ Change in the status of the PPS rebuilt by PTP

SNMP Trap Management

For each event related to the board, is generated a trap in parallel parallel to the machine set under TrapDest. The trap number reflects the event number and the contents of the SNMP variable associated contains the details (for example, the channel referred to the event).

User Account


The main user who has access to the apparatus is the administrator. He is able to change its credentials under *Account Settings*.



The screenshot shows a dark-themed web interface for 'Account Settings'. It features two input fields: 'Username' with the value 'admin' and 'Password' with the value '*****'. Below the password field is a 'Show characters' checkbox, which is currently unchecked.

It's possible set a user account that is able to use the apparatus remotely in read-only mode, without the possibility of changing its configuration.

The username and password for this *guest* account can be set by the administrator under *Guest Account Settings*.



The screenshot shows a dark-themed web interface for 'Guest Account Settings'. It features two input fields: 'Username' with the value 'guest' and 'Password' with the value '*****'. Below the password field is a 'Show characters' checkbox, which is currently unchecked.

The default credentials are:


admin	→	admin / admin
guest	→	guest / guest

About SNMP:

Read community string	→	public
Write community string	→	public


Custom Settings

The device permits to have some ad-hoc customizations through the unlock with particular activation codes.



Pulse Generation

The device is able to generate a programmable pulse in place of the IRIG-B DCLS signal (on the BNC connector) or the PPS signal.



The following parameters can be set:

- <Start Time> HH:MM:SS
- <Stop Time> HH:MM:SS
- <Repetition Rate> MM:SS
- <Pulse Length> SS.ssss

The system generates a sequence of pulses of <Pulse Length> length and repeating every <Repetition Rate> starting at <Start Time> and stopping at <Stop Time>.

Please note that the <Start Time> is always synchronous to the internal PPS (eventually disciplined via an external source).

Clock Generation

The device is able to generate two distinct programmable square wave clocks by dividing two different sources with integer dividers:

- 10 MHz
- 16.384 MHz

Please note that the rising edge of the resulting clock is synchronous to the internal PPS, if the frequency is integer.



Board Bring-Up

First installation

- GPS: eventually connect the GPS antenna cable to its connector GPS ANTENNA on the back
- IRIG-B: eventually connect the IRIG-B input to an IRIG-B master (OPTICAL or ELECTRICAL)
- PTP: eventually connect an Ethernet cable to the port/s on the back (it's required that the network is IEEE 1588 compliant for best operation)
- Connect the device to the power grid

Check-up

At the first start is a good idea to verify the correct operation of the apparatus.

For default factory settings the device IP address is **192.168.200.2** for the upper interface and **10.0.0.1** for the lower one.

To eventually discover the IP address in use, if different, is possible to use the **Autodiscovery** utility downloadable from the Digital Instruments website³, or to connect to the device via serial console and verify the ip address with the command **ifconfig** (eth0 is the upper network interface, eth1 the lower one).

Connect to the apparatus using a standard Web browser to `http:// <apparatus_ip>`

The default credentials are:

admin (read and write)	→	admin / admin
guest (read only)	→	guest / guest

From here, it's possible to check:

- Presence of the GPS antenna
In *GPS* tab of *Main Panel*, the *Antenna* LED should be green and, after a few minutes from switch on, even the *PPS Status* LED
- Presence of the IRIG-B signal and correct date and time
Can be checked in the IRIG-B tab of the *Main Panel*
- Presence of a master PTP
In the PTP tab of the *Main Panel*, the *State* variable should indicate *Slave*

³ <ftp://digiguest:guestd@www.digital-instruments.it/AutoDiscovery.zip>

Appendix A: Quality Factor

General Review


This appendix is intended to illustrate the meaning and motivation of the introduction of the Quality Factor within the Digital Instruments equipments.

Although the installation of a GPS device is relatively easy, it can hide certain issues that in some cases it can affect the proper functioning.

It is therefore expected to monitoring certain operating parameters so as to make immediate validation of a Circuit or finding the source of any problems.

GPS antenna positioning

GPS antenna should be positioned on a tower or on a roof with a good view of the GPS satellite constellation.



If not, the algorithm of regulation may not behave optimally and *short term stability* of the PPS and 10 MHz references it could be invalidated.

It's possible to evaluate the goodness of the positioning of the antenna in some ways:

1. checking the **power of received signal** from each satellite from the *Polar Plot*
2. checking and verifying that the **Quality Factor** is acceptable (typically > 25)
3. checking that the PPS generated by the radio (**PPS Status**) is valid (green LED)

It's possible get an idea of potential obstacles that limit the visibility of the GPS constellation to the radio observing the polar graph of satellites after a few hours of persistence.



Quality Factor

Quality Factor is the operating parameter that indicates the quality of the GPS signal received by the antenna. It is considered an acceptable value if > 25 . If the Q.F. is lower, it is possible that there are problems with the GPS signal reception and this involves a greater number of holdover and therefore a less precise synchronization.

The value of the Quality Factor is shown in *GPS* tab of *Main Panel* Page.

PPS Status: ■
 PPS Sync: ■
 Antenna: ■
 Position: ■
 Quality: ■ 28

Statistics

The device stores some useful statistical informations to evaluate the proper functioning over time:

- Holdover Num** shows the number of times that the GPS radio has entered into holdover mode in response to a problem (under optimal conditions should be low)
- Holdover Max** shows the duration of the longer hold-over (under optimal conditions should be low)
- Quality Min** indicates the smallest GPS antenna quality factor recorded (under optimal conditions should be high)
- PPS Dist Max** indicates the maximum distance affected by the PPS generated by the GPS radio (under optimal conditions should be low)
- Pos Alarm Num** indicates the number of times that there was a wrong geo-positioning under optimal conditions should be low)



It's a good idea to reset the stats before a capture session, because some values may be spurious in the first phase of synchronization or acquisition of satellites by the GPS radio.


Automatic Site Survey



In certain situations it may be convenient activate the *Positioning Mode* of GPS radio in *Automatic Site Survey*. In this mode the radio privileges the accuracy of temporal information at the expense of that position (as long as the antenna is not moved), so as to preserve signal integrity PPS in limited visibility conditions or in the GPS constellation or in presence of potential sources of interference.



If there are problems or abnormalities during the first installation or after moving the unit in a distant geographic location, GPS radio can be reseted by deleting the almanac and positioning information that is saved by the appropriate entry in the GPS menu. Should be also necessary to reset the device in *Automatic Site Survey* mode, since the radio, after completing the survey - which takes about 3 hours - automatically returns to *Position Hold* mode.



Appendix B: FAQ

D: Why is date and time not updating in the main web page?

R: You should check that the web browser is not caching pages. With Internet Explorer this can be done under Internet Options → General → Settings (in the Temporary Internet Files field) by checking that the setting "Check for newer versions of stored pages" is done "Every visit to the page".

The same approach can be used for the other web browsers as well (Mozilla Firefox, Google Chrome, Safari, ...)

D: The web interface is not correctly being shown.

R: It may be needed to update the Adobe Flash Player plug-in from the following internet web site <http://get.adobe.com/it/flashplayer/> (on-line installation) or from the following link <http://www.adobe.com/it/products/flashplayer/distribution3.html> (off-line installation)

D: How can I get additional info about the NTP service status?

R: The main informations are shown on the *Sources Config Panel* web page. Furthermore the device replies to *ntpq* queries. If it is not feasible to install it on a different PC it is still possible to connect to the device via telnet and issue the following commands:

```
cd /var/tmp  
./ntpq 127.0.0.1
```

Is now possible to query the NTP service with the commands shown in the following page:

<http://www.eecis.udel.edu/~mills/ntp/html/ntpq.html>

The most used commands are *peers*, *as e rv &n* (where *n* is the source number)

D: How can I configure the device as NTP client?

R: The syntax to be used is described at the following page:

<http://www.eecis.udel.edu/~mills/ntp/html/confopt.html#server>

For factory settings the device ships configured as NTP server. In order to configure it as a client is sufficient to add the following directive in the NTP configuration panel:

```
server x.x.x.x minpoll 4 maxpoll 4 prefer
```

D: How can I synchronize the device with the Win32Time service?

R: A few intermediate steps are needed. Since Windows synchronization is quite loose it may be discarded by the NTP client.

1. From the windows console digit:
`w32tm /config /manualpeerlist:,0x8 /syncfromflags:MANUAL`
2. Set the following registry key to 0 (via *regedit*)
`HKLM\SYSTEM\CurrentControlSet\Services\W32Time\Config\LocalClockDispersion`
3. Restart the *Windows Time Service*
4. Add the following line in the client NTP configuration file of the ETS-EVO²
`tinker panic 0 stepout 256
tos maxdist 2.5`

D: How can I test the NTP server quality?

R: A simple test is to configure an external client to listen to both the ETS-EVO² and a server from the Internet. Comparing the offsets with the *ntpq* program it is possible to get an idea about the precision of the synchronization.

Appendix C: Changelog

Software Versions

Release 6.8 (September 2014)

- First release supporting ETS-EVO²

Hardware Versions

Release 12 (September 2014)

- First release supporting ETS-EVO²

Assistance

For support requests please download the form from the website:

<http://www.digital-instruments.it/ita/assistenza.php>

Compile it in its entirety by specifying as precisely as possible and giving as many details as possible about the type of fault detected.

You can then send the form to **riparazioni@digital-instruments.com**, via fax to **+39.02.66506103**, or enter it directly into the box when sending goods for repair.

You can also contact us at +39.02.66506250 Monday to Friday from 9 to 13 and from 14 to 17 (GMT+1 Time).

Technical Data

Frequency Reference

Signal	10 MHz sine wave (Square wave optional), 2.048 MHz optional
Spectral Purity	-70 dBc (harmonic) -75 dBc (non-harmonic)
Phase noise	-130 dBc at 1kHz
Output	1
Output level	13 dBm
Output impedance	50 Ω
Output connector	BNC
Stability	1e-12 daily average (OCXO locked to GPS on SA) 1e-10 daily average (OCXO free run)
Options	Rubidium oscillator

Time Reference

Signal	1 PPS, 100µs Duty, Rising Edge
Output	1
Output level	TTL 5 Vpp, Square wave
Output impedance	50 Ω
Output connector	BNC

GPS Section

Receiver	12 Channels L1 1575.42 MHz
Tracking	Correlation on 12 satellites
PPS accuracy	< 50 ns on SA
Antenna connector	TNC
Collection time	< 4 min
Options	GPS + Glonass + Galileo ready

PTP Section

Network connection	N° 2 Ethernet 10/100/1000 interfaces
Protocol	IEEE 1588-2008 (PTPv2)
Role	Grandmaster clock source (GPS), slave or boundary clock
Time stamping	Hardware, Two-Step
Options	Multicast, Unicast, E2E, P2P, UDP/IPv4, Layer2
Profiles	Telecom, Power, Default
VLAN	802.1q

NTP Section

Protocol	NTP version 4
Role	Grandmaster clock source (GPS) or relay
Packet rate	20.000 transactions per second

Generated Time Codes

IRIG	User defined / IRIG-B DCLS / IRIG-B AM
Connectors	Electrical: BNC; Optical: ST

Signaling

Network connection	N° 2 Ethernet 10/100/1000 interfaces, TCP/IP protocol
Signaling	N° 5 led on front panel, LCD display
Serial Connection	RS-232 connector DB9 Male +/- 15 kV (ESD)
Remote signalling	7 Dry contact on Weidmuller connector with 3.5 mm step
Remote controllers	4 Dry contact on Weidmuller connector with 3.5 mm step

Supply

Input	N° 2 independent supply
Network	95 - 240 Vac Plug IEC320 integrated, filter EMI/RFI
Battery	18 - 36 Vdc / 36 - 72 Vdc

Certifications

CE

Sizes

Width	1 Unit 19"
Depth	300 mm without connectors
Weight	1.5 Kg

Accessories

- 1 x GPS Antenna
- 1 x 30 m Belden PRG 7 Cable
- 2 m Cordon for network supply
- 2 m Cordon for battery supply
- Handbook in English